



Patient Types

- Strict Ins and Outs
- Edema
- Urinalysis
- Low Urine Output
- Fluid Overload
- Sepsis / fever
- UOP assessment during or after surgery
- Eliminate CAUTI risk from indwelling catheter

Contact Us

Info@zorro-flow.com
205-377-0703



Proud Sponsor



For more information and videos
Scan her or go to

www.zorro-flow.com



Patient Types

- Strict Ins and Outs
- Edema
- Urinalysis
- Low Urine Output
- Fluid Overload
- Sepsis / fever
- UOP assessment during or after surgery
- Eliminate CAUTI risk from indwelling catheter

Contact Us

Info@zorro-flow.com
205-377-0703



Proud Sponsor



For more information and videos
Scan her or go to

www.zorro-flow.com



Patient Types

- Strict Ins and Outs
- Edema
- Urinalysis
- Low Urine Output
- Fluid Overload
- Sepsis / fever
- UOP assessment during or after surgery
- Eliminate CAUTI risk from indwelling catheter

Contact Us

Info@zorro-flow.com
205-377-0703



Proud Sponsor



For more information and videos
Scan her or go to

www.zorro-flow.com



Patient Types

- Strict Ins and Outs
- Edema
- Urinalysis
- Low Urine Output
- Fluid Overload
- Sepsis / fever
- UOP assessment during or after surgery
- Eliminate CAUTI risk from indwelling catheter

Contact Us

Info@zorro-flow.com
205-377-0703



Proud Sponsor



For more information and videos
Scan her or go to

www.zorro-flow.com



Patient Types

- Strict Ins and Outs
- Edema
- Urinalysis
- Low Urine Output
- Fluid Overload
- Sepsis / fever
- UOP assessment during or after surgery
- Eliminate CAUTI risk from indwelling catheter

Contact Us

Info@zorro-flow.com
205-377-0703



Proud Sponsor



For more information and videos
Scan her or go to

www.zorro-flow.com



Patient Types

- Strict Ins and Outs
- Edema
- Urinalysis
- Low Urine Output
- Fluid Overload
- Sepsis / fever
- UOP assessment during or after surgery
- Eliminate CAUTI risk from indwelling catheter

Contact Us

Info@zorro-flow.com
205-377-0703



Proud Sponsor



For more information and videos
Scan her or go to

www.zorro-flow.com



TO PLACE

1. Evaluate skin: don't use if abnormal.
2. If sterile technique desired, clean twice and be vigilant.
3. Identify all components before beginning.
4. Place adhesive on rim: LET DRY FOR 3-5 MINUTES.
5. Start with fresh diaper.
6. Place cup: start at bottom and place firmly for 30 sec.
7. Secure cup with tape strips.
8. Secure bag and tubing: assure not pulling and below bladder.

TO REMOVE

1. Use silicon based adhesive remover.
2. Never pull with force as this could damage skin

Guide is for reference only ©2025 Zorro-Flow inc.
and does not replace the IFU All Rights Reserved. LG-15 – Rev 4



TO PLACE

1. Evaluate skin: don't use if abnormal.
2. If sterile technique desired, clean twice and be vigilant.
3. Identify all components before beginning.
4. Place adhesive on rim: LET DRY FOR 3-5 MINUTES.
5. Start with fresh diaper.
6. Place cup: start at bottom and place firmly for 30 sec.
7. Secure cup with tape strips.
8. Secure bag and tubing: assure not pulling and below bladder.

TO REMOVE

1. Use silicon based adhesive remover.
2. Never pull with force as this could damage skin

Guide is for reference only ©2025 Zorro-Flow inc.
and does not replace the IFU All Rights Reserved. LG-15 – Rev 4



TO PLACE

1. Evaluate skin: don't use if abnormal.
2. If sterile technique desired, clean twice and be vigilant.
3. Identify all components before beginning.
4. Place adhesive on rim: LET DRY FOR 3-5 MINUTES.
5. Start with fresh diaper.
6. Place cup: start at bottom and place firmly for 30 sec.
7. Secure cup with tape strips.
8. Secure bag and tubing: assure not pulling and below bladder.

TO REMOVE

1. Use silicon based adhesive remover.
2. Never pull with force as this could damage skin

Guide is for reference only ©2025 Zorro-Flow inc.
and does not replace the IFU All Rights Reserved. LG-15 – Rev 4



TO PLACE

1. Evaluate skin: don't use if abnormal.
2. If sterile technique desired, clean twice and be vigilant.
3. Identify all components before beginning.
4. Place adhesive on rim: LET DRY FOR 3-5 MINUTES.
5. Start with fresh diaper.
6. Place cup: start at bottom and place firmly for 30 sec.
7. Secure cup with tape strips.
8. Secure bag and tubing: assure not pulling and below bladder.

TO REMOVE

1. Use silicon based adhesive remover.
2. Never pull with force as this could damage skin

Guide is for reference only ©2025 Zorro-Flow inc.
and does not replace the IFU All Rights Reserved. LG-15 – Rev 4



TO PLACE

1. Evaluate skin: don't use if abnormal.
2. If sterile technique desired, clean twice and be vigilant.
3. Identify all components before beginning.
4. Place adhesive on rim: LET DRY FOR 3-5 MINUTES.
5. Start with fresh diaper.
6. Place cup: start at bottom and place firmly for 30 sec.
7. Secure cup with tape strips.
8. Secure bag and tubing: assure not pulling and below bladder.

TO REMOVE

1. Use silicon based adhesive remover.
2. Never pull with force as this could damage skin

Guide is for reference only ©2025 Zorro-Flow inc.
and does not replace the IFU All Rights Reserved. LG-15 – Rev 4



TO PLACE

1. Evaluate skin: don't use if abnormal.
2. If sterile technique desired, clean twice and be vigilant.
3. Identify all components before beginning.
4. Place adhesive on rim: LET DRY FOR 3-5 MINUTES.
5. Start with fresh diaper.
6. Place cup: start at bottom and place firmly for 30 sec.
7. Secure cup with tape strips.
8. Secure bag and tubing: assure not pulling and below bladder.

TO REMOVE

1. Use silicon based adhesive remover.
2. Never pull with force as this could damage skin

Guide is for reference only ©2025 Zorro-Flow inc.
and does not replace the IFU All Rights Reserved. LG-15 – Rev 4

